



Vacuum Clamping Add-on for Project: EVS™, Project V2™, and Project: V4™ Vacuum Press Systems

The Project: EVS, V2, and V4 vacuum press systems can be used for much more than just veneering. With this clamping kit you can use the massive holding power of vacuum to instantly hold work pieces to your bench top for sanding, routing, carving and more. The latching pneumatic foot pedal can instantly apply or release vacuum to or from clamping jigs on your work bench. Vacuum clamping jigs are required to complete this clamping system. We offer everything needed to [make custom jigs](#) or simply order our versatile [Podzi clamping jigs](#).

By using a 3-way latching foot valve, pressure can be applied to the clamping jigs and release as needed. This kit doesn't force the pump to run continuously. Instead, the pump only runs when the vacuum reservoirs need to be recharged. Whether it's a simple hold down jig or a production run of vacuum template projects, you're going to get a kick out of using the power of vacuum to hold projects in place.

Warnings and Disclaimer

Brass products may contain chemicals known to the state of California to cause cancer or reproductive toxicity. Safety should be your highest priority when working with this tool. It is your responsibility to make sure you use this tool in a safe manner and in accordance with all safety policies in the work area. Wear appropriate safety equipment including hand and eye protection while using this tool. Use of this tool is at your own risk. JWW Services Inc. doing business as VeneerSupplies.com disclaims all responsibility for any resulting damage, injury or expense. The products contained in this kit are distributed, but not manufactured, by VeneerSupplies.com. Do not discard this instruction sheet.

System Compatibility

This kit is an add-on for the Project V2i , V4i , and EVSi vacuum press systems.

Parts List



Latching
Foot Valve



1/4" NPT Short
Street Elbow



1/4" NPT Long
Street Elbow



2" Brass
Pipe



Vacuum
Filter



Brass
Barb Elbow



Brass Vacuum
Clamping Fitting



1/4" NPT Brass
Hex Plug



Composite Plastic
Base Plate & Upright



12 Ft. Vacuum
Jig Tube



Miscellaneous
Screws



Thread Sealing
Tape

Warning: Brass products may contain chemicals known to the state of California to cause cancer or reproductive toxicity. Visit www.p65warnings.ca.gov for details.

PLEASE READ THIS SECTION CAREFULLY. IT CONTAINS A BINDING ARBITRATION CLAUSE THAT MAY SIGNIFICANTLY AFFECT YOUR LEGAL RIGHTS, INCLUDING YOUR RIGHT TO FILE A LAWSUIT IN COURT AND TO HAVE A JURY HEAR YOUR CLAIM(S).

The wording "We", "Us" and "Our" shall herein include JWW Services Inc., JoeWoodworker.com, VeneerSupplies.com, and its representatives, owners, and employees. Your use of this product is governed by the policies, terms and conditions set forth below and such use of the content and principles indicates your acceptance of these terms and conditions. These terms and conditions shall supersede any subsequent terms or conditions. JWW Services Inc. reserves the right to make changes to these terms and conditions at any time.

We do not make representations or give warranties regarding the use of this article. All content is provided for use as is without warranty of any kind. User indemnifies and holds JWW Services Inc. harmless from any and all actions, civil or criminal, claims, liabilities, and losses including our attorney fees, arising out of the use of this instruction set. The contents of this document are to be considered informational only and that which is not from an expert. This document, provided by JWW Services Inc., is non-expert opinion only and offered without warranty. You are solely responsible for your access to, use of and/or reliance on any content. You agree to conduct any necessary, appropriate, prudent, or judicious investigation, inquiry, research, and due diligence with respect to the safe and appropriate use of its contents.

JWW Services Inc. shall not assume any responsibility for any incident, accident, or other harmful occurrence in regard to the information or use of the information contained in this document. No warranty or representation, either expressed or implied, is made with respect to the quality, accuracy, safety or fitness for any part of this document. In no event shall we be liable for direct, indirect, special, incidental, or consequential damages arising from any information contained herein. The user/builder/owner of the system shall assume all risk. The full or partial assembling of this system is an agreement that you will not hold us liable for any circumstances or costs that may arise from the use of these parts and this system.

It is also agreed that we do not provide any form of insurance of fitness of this device for any use: commercial or otherwise. You hereby agree to hold us harmless for any mishap, injury, or untoward occurrence. Users of this document and the equipment described herein do so at their own risk and assume complete responsibility for the use of that information and equipment by themselves or others. We are not responsible for any personal injuries to the user/builder/owner or others associated with its uses, or property damage resulting from building or operating the equipment described herein. Maintaining equipment and evaluating its suitability for a specific situation are the sole responsibilities of the user/builder/owner. You agree to use the information contained in this document at your own risk and to use good judgment during the use of the equipment described in this document at all times and to work safely within your own abilities.

We shall not be held responsible for typographical errors. The products contained in this kit are distributed, but not manufactured, by VeneerSupplies.com.

Resolution of Claims or Disputes

Any dispute or claim between you and Us arising in any way out of the use of this site or any product contained within this site will be resolved by BINDING ARBITRATION, rather than in a court. This obligation applies to both parties, regardless of the legal theory or cause of action involved (tort, product liability, misrepresentation, negligence, etc.). Both you and Us agree to waive the right to bring a lawsuit to be decided by judge or jury regarding any such claims or disputes, and instead agree to have such claims or disputes resolved by an arbitrator.

Governing Law

The arbitrator shall be agreed upon by the parties and the arbitration shall take place in Harford County, Maryland in accordance with Maryland law.

Procedure

If the parties cannot agree on a mutually acceptable arbitrator, the arbitration will be conducted through the American Arbitration Association ("AAA") and in accordance with its rules. The AAA's rules are available to view at <https://www.adr.org>. Both parties agree to equally share the administrative expense of the arbitration, unless the arbitrator finds that the claim was brought in bad faith and orders one party to pay the cost of the proceedings as part of the arbitration award. Both parties are responsible for paying the costs of their own counsel, experts, and witnesses. Judgment on the award rendered by the arbitrator may be entered in any court having jurisdiction thereof. Before commencing an arbitration under this Agreement, the aggrieved party will first present the claim or dispute to the opposing party by (certified mail, regular mail). Our notice address to submit claims or disputes is: JWW Services Inc., 217 E. Jarrettsville Rd., Suite 5, Forest Hill, MD 21050. If the claim or dispute is not resolved within 90 days, the aggrieved party can commence arbitration proceedings in accordance with this Agreement.

Class Action Waiver

All arbitrations conducted under this Agreement shall be conducted only on an individual (and not a class-wide) basis; and an arbitrator shall have no authority to award class-wide relief. Your use of this document indicates your acceptance that this Agreement specifically prohibits you from commencing arbitration proceedings as a representative of others or joining in any arbitration proceedings brought by any other person.

Severability

If any part or any provision of this Agreement shall be finally determined to be invalid or unenforceable under applicable law, that part shall be ineffective to the extent of such invalidity or unenforceability only, without in any way affecting the remaining parts of said provision or the remaining provisions of this Agreement.

More information can be found at https://www.veneersupplies.com/pages/Legal__Information.html

Copyright

This article contains materials protected under copyright laws of the United States of America as well as International Copyright Laws. All rights reserved. No part of this article may be reproduced, transmitted, or transcribed electronically or otherwise without our expressed written permission. Information presented here and on any JWW Services Inc. website is intended for personal use only. Organizations whether they are profit, nonprofit, clubs, charities, web based groups or otherwise must obtain express permission from JWW Services Inc. prior to using any material for public demonstration.

Proposition 65 Warning (Assembly Bill 1953) To California and Other Applicable States

Brass products may contain chemicals known to the state of California to cause cancer or reproductive toxicity. This warning is provided to comply with California's Proposition 65 (Assembly Bill 1953) product labeling law and may apply to other states. Brass fittings and other products may contain chemicals known to the state of California to cause cancer, birth defects or other reproductive harm. Brass fittings may contain lead and are not for use with potable water. As with any product of this nature, we recommend washing your hands after contact with brass parts. We provide this warning based on our knowledge concerning the possible presence of one or more such chemicals, without attempting to evaluate the level of exposure. Visit www.p65warnings.ca.gov for details.



Pneumatics Assembly

1. Remove the four rubber feet on the bottom of the foot pedal using a screw driver. Discard the screws but save the rubber feet and the small washers.
2. Use the four #6 x 1/2" coarse-thread screws (included) to attach the rubber feet to the bottom of the composite plastic base plate. Pilot holes are not required for this step. The thicker rubber feet should be attached at the back of the base plate. The thinner rubber feet should be attached at the front of the base plate. Do not over-tighten the screws.
3. Attach the composite plastic "upright" piece to the base. This part fits snugly into the recess in the plastic base plate. Use the included black screws to secure the upright to the base plate. Pilot holes are not required. Do not over-tighten the screws.
4. All metal-to-metal connections will require thread-sealing tape. Wrap the tape clockwise around the fittings. Do not apply the tape to the brass fittings that will be attached to the vacuum filter.
5. Remove the plastic plugs from the three ports on the foot valve.
6. Use an Allen wrench to attach the brass hex plug to the B port on the foot valve.
7. Attach the brass street elbow to port "A" on the foot valve. When it is tight, it should be facing toward the "B" port.
8. Attach the 2" brass pipe to the street elbow from the previous step. The easiest way to tighten this fitting is with a pair of vice-grips. To prevent marring the brass, you can wrap masking tape around the pipe. There is no need to excessively tighten this fitting.
9. Remove the filter cover and filter element from the filter head being careful not to lose the rubber sealing ring inside.
10. Attach the filter head to the brass pipe on the foot pedal assembly. The arrow on the side of the filter head shows the correct direction of the vacuum flow. It should be pointing towards the foot pedal. The filter head is made from a soft composite plastic so be sure to avoid cross-threading as the fittings are attached. When the filter just becomes snug, continue tightening until the filter is parallel to the body of the foot valve as shown in the pictures on the next page. Do not over tighten the brass fittings that attach to the filter head.
11. Re-attach the filter element and filter cover to the filter head.
12. Attach the long brass street elbow to port "P" on the foot valve. When tight, the open port should be facing upward.
13. Attach the brass vacuum clamp fitting to the long brass street elbow.
14. Set the foot pedal assembly onto the composite plastic base plate so that the open port on the vacuum filter is inserted through the hole in the plastic upright support.
15. When positioning the foot pedal assembly, allow 1/8" of space so the clear filter canister can be removed for cleaning. Once the pedal is in the correct position, mark the base plate and drill a 5/32" pilot hole (1/2" deep) at the mounting tab on the left and right sides of the foot pedal.
16. Attach the foot pedal to the base plate with the included #12 x 3/4" screws.
17. Attach the brass barbed elbow to the remaining port on the filter. This fitting should be facing upward when fully tightened. Do not over-tighten this fitting.
18. Attach the blue vacuum jig tubing to the barbed fitting from the previous step. The other end of the tubing is connected to your vacuum clamping jig.

Instructions for Use

The Project: EVS, V2, and V4 vacuum press kits include a "lock-on" connector that is attached to the braided vacuum tube. Clip the lock-on connector to the brass vacuum clamping fitting on the foot pedal assembly. Be sure that the foot pedal is disengaged. Now open the vacuum valve on the vacuum press and turn on the system.

Attach the vacuum tubing from your vacuum jigs to the brass barbed elbow on the foot pedal assembly. Place the clamping jigs on a non-porous surface and set the project piece on top of the vacuum clamps. Depress the foot pedal until it clicks and then release. This will open the flow of vacuum to the jigs and will instantly clamp the project in place.

To release the clamping pressure, depress the foot pedal again.

The final assembly should appear as shown in the pictures below.

