

Warnings

Safety should be your highest priority when working with this item. It is your responsibility to use and handle it in a safe manner and in accordance with all safety policies in the work area. Wear appropriate safety equipment including eye and ear protection while using this item.



To avoid danger of suffocation, keep this bag away from babies and children. Do not use this bag in cribs, beds, carriages or play pens. This bag is not a toy.

Brass products may contain chemicals known to the state of California to cause cancer or reproductive toxicity.

Use of this item is at your own risk. JWW Services Inc. doing business as VeneerSupplies.com disclaims all responsibility for any resulting damage, injury or expense. For more information please visit https://www.veneersupplies.com/pages/Legal__Information.html

The products described herein are distributed, but not manufactured, by VeneerSupplies.com.

Introduction

VS Elite™ and VS Extreme™ polyurethane are the ultimate vacuum bagging materials. The material is shipped as a “tube” of polyurethane. In other words, it has two open ends. This bag material was designed exclusively for VeneerSupplies.com using an advanced thermoplastic polyurethane that can withstand pressures exceeding 3,750+ psi and stretch more than 6 times its width and length. The polyurethane film, bag stem and bag closure are made in the USA.


Included Items

VS Elite/Extreme™ polyurethane vacuum bag material, brass stem insert and two bag closures.

C-Type Bag Closure

The Build-a-Bag kit comes with two bag closures which are used to seal each end of the bag. Some users find that it is easier to load a project into a vacuum bag with the assistance of a second person who works from the opposite end of the bag (guiding the project into the bag). If you have a small project or do not have someone to help, you can apply a bag closure to one end of the vacuum bag before loading the project.

The PVC closure system included with your vacuum bag will allow you to easily seal the bag opening. Simply roll the bag end over the PVC tube. Then snap the PVC C-channel over the bag starting from one side and working towards the opposite side. To ensure a perfect seal, be certain that the entire bag opening is secured by the closure and that there are no wrinkles in the bag material.



For additional clamping strength, you can attach spring clamps over the C-channel. This is not necessary under normal conditions but it will provide a better seal if the bag or closure is heavily worn. For the ultimate gripping strength, the bag may be rolled over the tube twice before the C-channel is attached. We do not recommend more than a double roll over the tube due to the difficulty of removing the closure under such clamping pressure.

A light coat of car wax will make it easier to snap the bag closure over the vacuum bag.

Flush Mount Bag Stem

The flush-mount bag stem allows you to use the full length of the vacuum bag without worry of project surface imperfections. The stem can be mounted anywhere on the bag but we recommend mounting it centered across the width and approximately 15" from the bag opening. The location will not affect the pressure inside the bag.

1. Mark the location on the vacuum bag where you wish to install the bag stem.
2. In the selected area, cut a 3/8" diameter hole in the vacuum bag using scissors or a razor knife.
3. A small tube of cement is included with your bag stem kit. This cement will work with both vinyl and polyurethane materials. Be sure to follow the safety instructions included with the cement and wear appropriate eye, skin, and lung protection when using this product.
4. In a well ventilated area, clean the mating surfaces of the bag stem flange and the vacuum bag with acetone. A synthetic abrasive pad will help maximize the effectiveness of the cleaner. When completed, the cleaned areas should look dull and abraded.
5. The included cement will be used to bond the bag stem flange to the vacuum bag. Apply the cement to the bottom of the flange and to the vacuum bag area where the bag stem will be attached. Be sure there is full coverage on both pieces.
6. Apply the flange directly over the bag hole (from step 2). Gently massage out any air bubbles but try not to squeeze out too much of the cement. Allow 24 hours of drying time before using the vacuum bag. If the flange starts to lift from the bag surface while the cement is curing, press it in place again and place some weight on the flange.
7. Insert the brass barbed stem core that is included with this kit. Proceed carefully since the edges of the barbs are sharp. Once inserted, the stem core is not easily removed. Warning: Brass products may contain chemicals known to the state of California to cause cancer or reproductive toxicity.

Avoid These Common Mistakes - PLEASE READ CAREFULLY

Extend the service life of the vacuum bag by using and storing it carefully. Be sure to round over the protruding edges of anything placed inside the bag including the platen. When you finish using the vacuum bag, store it away from direct sunlight and other UV sources such as fluorescent lighting.

It is imperative that the user prevents the vacuum bag from being vacuumed into any deep openings in the project or project form. Vacuum can cause the bag to stretch into these openings and create a reverse bubble which will eventually burst. The resulting damage will not likely be repairable. Use a suitable material that safely covers these openings and prevents the bag material from going inside the project.

Vacuum Bag Maintenance

Polyurethane is much more resilient than vinyl and with ordinary use, will last for a very long time. You can extend the service life of the vacuum bag by using and storing it carefully. Be sure to round over the protruding edges of anything placed inside the bag including the platen. When you're finished with the vacuum bag, store it away from direct sunlight.

In the unlikely event that your bag develops a leak, the easiest way to find it is to place a piece of brown paper in the area where you suspect there is a leak. Then place the platens inside the bag and clamp it shut. Next, turn on the vacuum unit and allow it to achieve as much pressure as possible. Now spray the outside of the bag with water. Any holes in the bag will show up on the paper as the water is absorbed. To repair the leak, contact us for a patch kit.