




VeneerSupplies.com Veneer Punch

It's not uncommon to find bark patches and other voids in burl veneer. This tool allows the user to easily punch out the defect and replace it with a reciprocal patch. A tremendous amount of thought and experience led to the unique design and machining of this highly sought-after hand tool. Each tool begins as a solid billet of A2 tool steel and undergoes a multi-pass machining process on a specialized CNC lathe and end-mill. No finer veneer punch has ever been made!



If you are familiar with traditional veneer punches, you know they have a tendency to blow out the surrounding veneer. This can only be minimized by applying masking tape to the veneer face which holds the veneer tight as the pressure of the punch presses downward and outward. In its very essence, that style of tool is destined to create problems. Unlike traditional punches, this tool has the bevel on the inside. This practically eliminates any external splitting and with this updated design, the pressure of the bevel is inward toward to the patch piece.

The simplicity of this heavy duty tool is what makes it a true pleasure to use. This tool is excellent for use with all burl species. Please note that the brass handle will tarnish. We recommend a coat of spray lacquer (used according to directions) if you would like to keep the tool looking new.

Warning: Brass products may contain chemicals known to the state of California to cause cancer or reproductive toxicity. Visit www.p65warnings.ca.gov for details.



Caution: The edges of this tool may be extremely sharp. Use with care.

1. Not for use with veneers that exceed 1/42" thick.
2. Place a small piece of soft wood lumber such as pine, poplar, or walnut under the veneer to be punched. Do not back the veneer with a hard wood such beech, birch, cherry, or maple. The tool edge is delicate and the tool steel will break if excessive force is used or if the wood behind the veneer is too hard.
3. Veneers must be treated with veneer softener (such as Super Soft 2i) a minute or two before punching out a veneer patch to make the cut cleanly and easily. No warranty is offered on this tool if use on veneers which have not been treated with veneer softener.
4. Hold the tool carefully and keep your fingers away from the striking surface of the punch. Lightly strike the tool with a wood or rubber mallet to punch out a test patch piece on scrap veneer. A lead-blow+or shot-filled mallet works very well.
5. If the punch does not make a full cut through the test veneer, try striking the tool with additional force. Do this to understand the amount of force required to make a clean cut without the use of excessive force which will damage the cutting edge.
6. Once the amount of striking force has been established, use the tool to punch out the defect in the project's veneer sheet.
7. Align the tool to the grain of the replacement veneer and punch out the patch.
8. Set the patch into the punched hole in the good veneer sheet and apply a small piece of veneer tape (on the top surface) to hold it in place while being pressed.

**Warning: This Tool Contains Sharp Edges
Do not discard this instruction sheet.**

Safety should be your highest priority when working with this tool. It is your responsibility to make sure you use this tool in a safe manner and in accordance with all safety policies in the work area. Wear appropriate safety equipment including hand and eye protection while using this tool. Always store the tool inside the box. This product is distributed, but not manufactured, by VeneerSupplies.com.

Use of this tool is at your own risk. JWW Services Inc. doing business as VeneerSupplies.com disclaims all responsibility for any resulting damage, injury or expense. If you do not agree to these terms, please return the unused tool to us within 30 days of receipt.